

# Recommended Fuses & Fuse Holders

Fuse	amp	1 pole open holder	2 pole open holder	3 pole open holder	cover (1 per fuse)		1 pole ultrasafe	2 pole ultrasafe	3 pole ultrasafe
					w/o ind	w/ ind			
A25Z-2	1-30	30311	30312	30313	DFC-7	DFC-7I	USM1(I) *	USM2(I) *	USM3(I) *
A2D	1/10-30	20306R	20307R	20308R	DFC-9	DFC-9I			
A2D	35-60	20606R	20607R	20608R	DFC-13	DFC-13I			
A2D	70-100	21036R	21037R	21038R	DFC-4	DFC-4I			
A2D	110-200	22001R	---	22003R	---	---			
A2D	225-400	24031R	---	24033R	---	---			
A2D	450-600	2631R	---	2633R	---	---			
A2K	1-30	20306R	20307R	20308R	DFC-9	DFC-9I			
A2K	35-60	20606R	20607R	20608R	DFC-13	DFC-13I			
A2K	70-100	21036R	21037R	21038R	DFC-4	DFC-4I			
A2K	110-200	22001R	---	22003R	---	---			
A2K	225-400	24031R	---	24033R	---	---			
A2K	450-600	2631R	---	2633R	---	---			
A3T	1-30	30306T	30307T	30308T	---	---			
A3T	35-60	30606T	30607T	30608T	---	---			
A3T	70-100	31001T	31002T	31003T	---	---			
A3T	110-200	32031T	---	32033T	---	---			
A3T	225-400	34031T	---	34033T	---	---			
A3T	450-600	36031T	---	---	---	---			
A3T	700-800	1SC375	---	---	---	---			
A4BQ	100-800	---	---	P48F	---	---			
A4BQ	900-1200	---	---	P412F	---	---			
A4BT	200-800	---	---	P48F	---	---			
A4BT	900-1200	---	---	P412F	---	---			
A4BY	200-800	---	---	P48F	---	---			
A4BY	801-1200	---	---	P412F	---	---			
A4J	1-30	60306SJ	60307SJ	60308SJ	DFC-10	DFC-10I	US3J1(I) *	US3J2(I) *	US3J3(I) *
A4J	35-60	60606J	60607J	60608J	DFC-6	DFC-6I	US6J1(I) *	US6J2(I) *	US6J3(I) *
A4J	70-100	61036J	61037J	61038J	DFC-3	DFC-3I			
A4J	110-200	62001J	---	62003J	DFC-12	DFC-12I			
A4J	225-400	64001J	---	64003J	---	---			
A4J	450-600	6631J	---	6633J	---	---			
A6D	1/10-30	60306R	60307R	60308R	DFC-2	DFC-2I			
A6D	35-60	60606R	60607R	60608R	DFC-5	DFC-5I			
A6D	70-100	61036R	61037R	61038R	DFC-8	DFC-8I			
A6D	110-200	62001R	---	62003R	---	---			
A6D	225-400	64031R	---	64033R	---	---			
A6D	450-600	6631R	---	6633R	---	---			
A6K	1-30	60306R	60307R	60308R	DFC-2	DFC-2I			
A6K	35-60	60606R	60607R	60608R	DFC-5	DFC-5I			
A6K	70-100	61036R	61037R	61038R	DFC-8	DFC-8I			
A6K	110-200	62001R	---	62003R	---	---			
A6K	225-400	64031R	---	64033R	---	---			
A6K	450-600	6631R	---	6633R	---	---			
A6T	1-30	60306T	60307T	60308T	---	---			
A6T	35-60	60606T	60607T	60608T	---	---			
A6T	70-100	61031T	61032T	61033T	---	---			
A6T	110-200	62031T	---	62033T	---	---			
A6T	225-400	64031T	---	---	---	---			
A6T	450-600	66031T	---	---	---	---			
A6T	700-800	1SC375	---	---	---	---			
A6Y-2B	1/4-30	30311	30312	30313	DFC-7	DFC-7I	USM1(I) *	USM2(I) *	USM3(I) *

Continued...

# Recommended Fuses & Fuse Holders

Fuse	amp	1 pole open holder	2 pole open holder	3 pole open holder	cover (1 per fuse)		1 pole ultrasafe	2 pole ultrasafe	3 pole ultrasafe
					w/o ind	w/ ind			
AG	1/2-15	40111G	40112G	40113G	---	---			
AG	20	40211G	40212G	40213G	---	---			
AG	25-30	40311G	40312G	40313G	---	---			
AG	35-50	40606G	40607G	40608G	---	---			
AJT	1-30	60306SJ	60307SJ	60308SJ	DFC-10	DFC-10I	US3J1(I) *	US3J2(I) *	US3J3(I) *
AJT	35-60	60606J	60607J	60608J	DFC-6	DFC-6I	US6J1(I) *	US6J2(I) *	US6J3(I) *
AJT	70-100	61036J	61037J	61038J	DFC-3	DFC-3I			
AJT	110-200	62001J	---	62003J	DFC-12	DFC-12I			
AJT	225-400	64001J	---	64003J	---	---			
AJT	450-600	6631J	---	6633J	---	---			
ATDR	1/4-30	30311R	30312R	30313R	DFC-7	DFC-7I	USCC1(I) *	USCC2(I) *	USCC3(I) *
ATM	1/10-30	30311	30312	30313	DFC-7	DFC-7I	USM1(I) *	USM2(I) *	USM3(I) *
ATMR	1/10-30	30311R	30312R	30313R	DFC-7	DFC-7I	USCC1(I) *	USCC2(I) *	USCC3(I) *
ATQ	1/10-30	30311	30312	30313	DFC-7	DFC-7I	USM1(I) *	USM2(I) *	USM3(I) *
ATQR	1/10-30	30311R	30312R	30313R	DFC-7	DFC-7I	USCC1(I) *	USCC2(I) *	USCC3(I) *
GFN	1/10-10	30311	30312	30313	DFC-7	DFC-7I	USM1(I) *	USM2(I) *	USM3(I) *
GGU	3-30	30311	30312	30313	DFC-7	DFC-7I	USM1(I) *	USM2(I) *	USM3(I) *
HSJ	1-30	60306SJ	60307SJ	60308SJ	DFC-10	DFC-10I	US3J1(I) *	US3J2(I) *	US3J3(I) *
HSJ	35-60	60606J	60607J	60608J	DFC-6	DFC-6I	US6J1(I) *	US6J2(I) *	US6J3(I) *
HSJ	70-100	61036J	61037J	61038J	DFC-3	DFC-3I			
HSJ	110-200	62001J	---	62003J	DFC-12	DFC-12I			
HSJ	225-400	64001J	---	64003J	---	---			
HSJ	450-600	6631J	---	6633J	---	---			
OT	1-30	20306	20307	20308	DFC-9	DFC-9I			
OT	35-60	20606	20607	20608	DFC-13	DFC-13I			
OT	70-100	21036	21037	21038	DFC-4	DFC-4I			
OT	110-200	22001	---	22003	---	---			
OT	225-400	24031	---	24033	---	---			
OT	450-600	2631	---	2633	---	---			
OTM	1-30	30311	30312	30313	DFC-7	DFC-7I	USM1(I) *	USM2(I) *	USM3(I) *
OTS	1-30	60306	60307	60308	DFC-2	DFC-2I			
OTS	35-60	60606	60607	60608	DFC-5	DFC-5I			
OTS	70-100	61036	61037	61038	DFC-8	DFC-8I			
OTS	110-200	62001	---	62003	---	---			
OTS	225-400	64031	---	64033	---	---			
OTS	450-600	6631	---	6633	---	---			
TR	1/10-30	20306R	20307R	20308R	DFC-9	DFC-9I			
TR	35-60	20606R	20607R	20608R	DFC-13	DFC-13I			
TR	70-100	21036R	21037R	21038R	DFC-4	DFC-4I			
TR	110-200	22001R	---	22003R	---	---			
TR	225-400	24031R	---	24033R	---	---			
TR	450-600	2631R	---	2633R	---	---			
TRM	1/10-30	30311	30312	30313	DFC-7	DFC-7I	USM1(I) *	USM2(I) *	USM3(I) *
TRS	1/10-30	60306R	60307R	60308R	DFC-2	DFC-2I			
TRS	35-60	60606R	60607R	60608R	DFC-5	DFC-5I			
TRS	70-100	61036R	61037R	61038R	DFC-8	DFC-8I			
TRS	110-200	62001R	---	62003R	---	---			
TRS	225-400	64031R	---	64033R	---	---			
TRS	450-600	6631R	---	6633R	---	---			
TRS-RDC	1/10-30	60306R	60307R	60308R	DFC-2	DFC-2I			
TRS-RDC	35-60	60606R	60607R	60608R	DFC-5	DFC-5I			
TRS-RDC	70-100	61036R	61037R	61038R	DFC-8	DFC-8I			
TRS-RDC	110-200	62001R	---	62003R	---	---			
TRS-RDC	225-400	64031R	---	64033R	---	---			

(I)\* - add I at the end of the part number for the indicating version

USA T 978 462 6662 F 978 462 0181 info.nby@mersen.com

CANADA T 416 252 9371 F 416 252 6572 sales.tor@mersen.com

ep-us.mersen.com

FERRAZ SHAWMUT IS NOW MERSEN

